



BELCO GLASS, INC. USA
340 Edrudo Road
Vineland, NJ 08360

Fyrite Reading Instructions:

Note: Be sure to hold canister away from face. Do not press button with canister inverted. To ensure accuracy, it is important to always follow the same procedure when taking a Fyrite reading.

- 1) Press button on top of Fyrite canister to release CO₂ concentration. Tip canister to the side to ensure all fluid is released from top of canister.
- 2) Loosen screw on slide scale & align top of fluid with zero on the scale. Tighten screw.
- 3) Connect hose & bulb to unit being tested.
- 4) Place hose directly over button on top of canister & press firmly.
- 5) With button depressed, squeeze bulb 27 times. On the last squeeze, with bulb still deflated, release hose from button.
- 6) Turn Fyrite canister upside down 3 times, each time allowing all fluid to flow to the opposite end of the canister.
- 7) Tip canister slightly to ensure all fluid has been released from top of canister.
- 8) Read CO₂ concentration in %.

Note: Your Fyrite indicator will come with a complete set of detailed instructions which should be followed carefully. The fluid used inside this Fyrite instrument is poisonous & corrosive & must not be taken internally. In event of a spill or accidental body contact with the Fyrite fluid, follow instructions on the refill bottle carefully.

